


Oxford Carriage Door Ltd.


25 Griffith Road, Stratford, Ontario, Canada N5A 6S4
Office: 519-814-2630 - Fax: 519-814-3172

CEDAR WEATHER STRIP CAP INSTALLATION INSTRUCTIONS


1-Install the Elton SA-5001 weather strip onto the jamb as per typical residential weather strip.




2-Once the weather strip is installed onto the jamb, measure the cedar cap and cut it to length with the preferred method being to mitre the corners.



3-Place the cedar cap over the aluminum retainer and drill a 1/8" pilot hole 1" from the end and then every 16" from there through the cedar cap and aluminum retainer. (Fig. 1)



4-Secure the cedar cap to the Elton SA-5001 weather strip using stainless steel #8-18 x 1-1/2" pan head self-drilling screws. (Fig. 2)



5-As an alternative method, 15 gauge x 1-1/2" stainless steel finishing nails can be used to fasten the cedar cap in lieu of the #8 self drilling screws. (Fig. 3)